




COM SLIM 20

Aluminum sound column loudspeaker



COM SLIM 20

The compact column loudspeaker **COM SLIM 20** is designed for corner or wall installation. This column loudspeaker reproduces speech with perfect transparency.

There is an input impedance selector of 8-position for power adaptation. COM SLIM 20 consists of 5 wide band loudspeakers of 50 mm diameter. Dedicated accessories make installations especially easy. This column loudspeaker is designed for churches, but mechanical structure makes it ideal also for all "long-hall" echo typed places.

TECHNICAL SPECIFICATIONS

	COM SLIM 20
Rated power	20W
Transformer power taps	2.5W-5W-10W-20W
Sensitivity	88 dB
Maximum SPL	101 dB ± 3 dB
Frequency response	200 Hz - 20 kHz
Driver dimensions	5 x 2" (50 mm)
Dimensions	433 x 65 x 53 mm
Weight	1.8 kg
Material	Aluminum
Colour	White