

VIVA 5 Wall mount plastic loudspeakers



TECHNICAL SPECIFICATIONS



VIVA 5

VIVA 5 the first speaker of a totally new design series speakers from AMC. Increased sound quality, progressive design and functionality.

Elegant contemporary design, smooth cabinet surface and mild grill. Classic shape with its advanced twist that lets the loudspeaker to adapt easily in a wide variety of contemporary interiors and become an integral part of the architecture. Rotating AMC logo, newly designed U-bracket enables a wide array of mounting possibilities. The semi-circle bracket not only looks good, but also lets easily adjust the mounting angle within 15 degree angle. Power adjustment of the speaker is very simple. The ultra thin and flat power selector looks very elegant. Integrated Phoenix connectors show advanced design of the loudspeaker. Three colour choice. Two-way loudspeaker with 5 inch low frequency and 1 inch silk tweeter inside.

	VIVA 5
Rated power	30 W (8 Ω)
Transformer power taps	25 W - 15 W - 10 W - 5 W - 8 Ω
Sensitivity	88 dB (1 W/1 m)
Maximum SPL	104 dB (Pmax/1 m) at 7015 Hz
Frequency response	110 Hz – 20 kHz
Dispersion at 1000 Hz	180° (H), 160° (V)
Driver dimensions	5" (127 mm) woofer, 1" (25,4 mm) tweeter
Dimensions	245 mm x 175 mm x 170 mm
Weight	2,4 kg
Material	Housing – plastic, grill and U-bracket steel
Colour	White (RAL9016), white (RAL 9018), black (RAL 9017)

unit: mm

VIVA 5

