



## EVAC6

### Metal ceiling loudspeaker with fire dome



#### EVAC range

**Metal ceiling loudspeaker with built-in 100V transformer, metal grill, orange steal fire housing, white color speaker.**

Designed to be mounted recessed in hanging false ceilings or panels, the EVAC6 is perfect for background music and announcements. In compliance with BS5839 part 8, EVAC6 incorporates a ceramic terminal and thermal fuse and is suitable for use in voice alarm applications.

TECHNICAL SPECIFICATIONS	
	EVAC6
Rated power	10 W
Transformer power taps	10W - 5W - 2.5W
Sensitivity (@ 1 m/1 W)	93 dB
Maximum SPL	102 dB ± 3 dB
Frequency response	150 Hz - 20 kHz
Driver dimensions	6" (152 mm)
Dimensions	∅ 200 x 100 mm
Weight	1.43 kg
Material	Steal
Color	Speaker - White (WT), Fire dome - Orange (RAL2008)

